



**urbanmac**  
GARDEN BOXES FOR CITY FOLK

## Hints and Tips to Assemble your Compost Bin

### GET IN TOUCH

**PHONE**  
09 236 3727

**EMAIL**  
[sales@urbanmac.co.nz](mailto:sales@urbanmac.co.nz)

**WEB**  
[www.urbanmac.co.nz](http://www.urbanmac.co.nz)

Your kitset will contain:

- 2 ends pre-assembled 6 long rails.
- 5 short rails with lugs. 7 rails without lugs (6 for the back and 1 for bottom front).
- 16 x 75mm Stainless Steel Square Drive self-tapping wood screws.

1. You'll need a "square drive" screwdriver bit and power drill. (You can do it without a power drill and just a hand screwdriver but then you would also need a gorilla because humans just aren't strong enough to do it alone).
2. Set it up where you want to leave it and make sure that you can either walk around it or reach all four corners. Otherwise you will end up with parts of your compost bin that you can't use.
3. You might notice that we haven't made holes in the lengths of timber which you screw into. We did that on purpose to help the screw take a better grip.
4. You will need to push on the screws reasonably hard as they go in and be careful not to round off the part on the screw where the screwdriver fits. If that happens and the screw is only halfway in, well - you're screwed!
5. The screw tops need to go at least halfway into the post. We have drilled the holes big enough for the screw head to fit into.
6. Separate the side frames received which are pre-assembled.
7. Separate the loose boards (front boards have the lugs attached)
8. Attach plain long boards at the back and front. Make sure they are flush with the bottom.
9. Attach remaining rear boards matching the gap on the side rails.
10. Drop in the front boards with spacers. (option to screw 2<sup>nd</sup> board up)

### **13. Fill it up!**

If you have any problems - give us a call, we might be able to help guide you over the phone.